

PXIE Vacuum Considerations

Alex Chen, Lucy Nobrega

Dec. 13, 2011

Outline


- Motivation
- Vacuum Requirement
- Gas loads
- Pumping Scheme
- Considerations of Low Particulate Vacuum
- Operational concerns
- R&D proposal
- Summary

Motivation

- Establishing communication with entire project about vacuum requirement, we all live together in the vacuum environment
- Integrate vacuum requirement in machine design, key component design, instrument design, to reduce the likelihood of problems late, such as material choices compatible with UHV and low particulate requirements
- Lesson learned from HINS RFQ
 - ▣ Thorough leak check during the steps of construction of component
 - ▣ Improper vacuum seal method
 - ▣ Need of vacuum person get involved at the design stage of project

the Vacuum Requirement of PXIE


- Residual gas pressure?
 - ▣ driven by reasonable beam loss due to beam-gas interaction or required by specific instrument in order function properly
- Gas species sensitive?
 - ▣ H_2 , N_2 , H_2O , Ar, CO_2 , hydrocarbons
- Particle count for SRF?
 - ▣ class 1, 10, 100, 1000,...
- Contamination control:
 - ▣ segmentation, migration, locations of pumping, venting
- Real-time monitoring
 - ▣ pressure gauges, pump status, partial pressure ratio(RGA)



the Vacuum Requirement of PXIE

- Materials used in vacuum
 - Outgassing (rate and species)?
 - Producing particles?
- Design
 - Vacuum Seal design: brazing, welding, or flanged(metal or O-ring)
 - Avoiding virtual leak: blind screw; double joint; ...
- Procedures for QC:
 - Machining: cutting fluids ...
 - Cleaning: material specific, Cu, SS, Al, ...
 - Handling: groves, foils, tools, clean area,
 - Thorough leak check before major steps
 - Certified before installation in the system
- Management Policy
 - vacuum experts shall involved in major design reviews


A virtual leak is a volume of trapped atmospheric gas that leaks into the vacuum vessel through holes or cracks that do not go all the way through the vessel wall.



Accelerator Vacuum Engineering
By Louis R. Bertolini, LLNL

Gas loads in PXIE

- **H⁻ Ion source ($\sim 10^{-1}$ torr.l/s)**
 - H₂ introduce by pulse valve, in order to make H⁻
 - maintain proper pressure, $\sim 10^{-5}$ torr
- **RFQ ($\sim 10^{-5}$ torr.l/s)**
 - permeation thru O-rings, $\sim 10^{-6}$ torr.l/s
 - surface outgassing, $\sim 10^{-6}$ torr.l/s
 - gas flows from LEBT, $\sim 10^{-6}$ torr.l/s
 - Beam neutralization, $\sim 10^{-5}$ torr.l/s
- **MEBT ($\sim 10^{-4}$ torr.l/s) and Diagnosis lines and beam dump**
 - significant H₂ production from absorber, $\sim 10^{-4}$ torr.l/s
 - outgassing from every devices exposed in vacuum, such as cavities, beamtubes, beam instrumentation... $\sim 10^{-5}$ torr.l/s
- **Cryomodules**
 - Insulating vacuum: large and dirty, but low requirement
 - Coupler vacuum: not significant
 - Vaporization from condensation due to temperature rise(sensitive)
 - Cavity vacuum: from warm section, depends on pressure and conductance




By Steve Virostek

Gas loads in PXIE

□ Without DP between MEBT and CM


- H_2 due to 10mA beam neutralized at absorber $Q=9.6E-4$ torr.l/s
- assume 3000 l/s effective pumping
- Pressure at Absorber: $P=3.2E-7$ torr
- Aperture of beamtube: $d=1.37''$
- Distance of absorber to CM: $L=2.5m$
- Flux to CM: $Q=2.4E-6$ torr.l/s
- $d1=40mm$, $l1=400mm$
- One monolayer time: 1.8 hours
- Then the CM get flooded quickly



Zachary Conway of ANL

Gas loads in PXIE

- With DP, and if we can achieve $3\text{E-}10$ torr at front of CM
 - ▣ Flux to CM: $Q \sim 10^{-10}$ torr.l/s
 - ▣ $d_1 = 40\text{mm}$, $l_1 = 400\text{mm}$
 - ▣ One monolayer time: ~ 5000 hours



We are still in discussions with vendors. This geometry is not final.

Zachary Conway of ANL

Pumping Scheme

- H^- Ion source (10^{-5} torr)
 - ▣ Turbo pumps backed by mechanical dry pump with filter
- RFQ (10^{-8} torr)
 - ▣ Turbo pumps backed by mechanical dry pump with filter
- MEBT (10^{-7} torr), Diagnosis lines & beam dump
 - ▣ distributed ion pump + turbo pumps with filter @ absorber + differential pumping near CM
 - ▣ achieve 10^{-10} torr where near CM
- Cryomodules ($<10^{-10}$ torr)
 - ▣ Beam vacuum, Pumped 10^{-7} by turbo pumps until cooled down (dry pump with filter)
 - ▣ Insulating vacuum: pumped down 10^{-4} by turbo until cooled, maintained by turbo as needs. Self-sustained 10^{-6} torr at cold.
 - ▣ Coupler vacuum: pump down by turbo and maintained with ion pump.
- All venting (except insulating vacuum) shall be slow and with filters.
 - ▣ control mas flow to <40 torr.l/s until pressure < 1 torr. according to DESY
 - ▣ Design venting locations so that particle migrates not toward CM
 - ▣ Controlled venting/pumping system with mass flow controllers currently being developed by NML

Particle Free Vacuum Requirement

Vacuum Requirement for MEBT to Assure SRF Survival

- Sharp metal particulate could destroy SRF cavities
- Entire beamline should be particle free because of potential of particle migration (during pump down and vent-up)
- In practice, systems can have non-particle free components but trend is to remove them
 - ▣ CEBAF considering removal of sintered NEG because of shedding
 - ▣ XFEL has removed most TSP's

Particle Free Handling & Assembly

Vacuum Requirement for MEBT to Assure SRF Survival

- Low particulate vacuum handling and assembly practices should be employed for the entire beamline. Estimate $\sim 4x$ more time than normal UHV installation. Special procedures include
 - ▣ all preassembly/assembly work done in Class 10 or 100 cleanrooms
 - ▣ open beamline work always to be done in a portable cleanroom
 - ▣ stricter gowning requirements
 - ▣ blow down all parts/hardware as being assembled according to procedure

Absorber Risk to SCRF Cavities

Vacuum Requirement for MEBT to Assure SRF Survival

- Absorber is a danger to SCRF cavity by
 - ▣ Shedding of copper particulate
 - ▣ Close proximity to cavity (2m)
- Options to explore if absorber must be used:
 - ▣ Move it farther away from cryomodule (still risky due to particle migration)
 - ▣ Include fast acting gate valves protect in certain cases of catastrophic failure
 - ▣ Minimize line of sight to cavities to reduce chance that particles will be 'picked up' by flowing gas
 - ▣ Add pumping as close as possible to absorber to pull gas toward pumps and not sensitive surfaces
 - ▣ Add some sort of 'dust collector'
 - ▣ Continue investigating...

Operational Concerns

- Datalogging the status of all vacuum devices, necessary for operation and analysis
- Interlocking fast valves at both ends of CM, but no much meaningful protection from vacuum failure within 10m, so low particulate vacuum practice shall apply on entire PXIE beamline
- Realtime RGA, try to detect slow leaks, R&D needs
- Gauging: double gauges shall be used to reduce access time and increase system reliability
- Operating procedures to reduce human errors, such never venting coupler vacuum when CM is cold, etc.
- Vacuum Training:
 - Human error is always major risks in Vacuum practice
 - Fermilab has not been used to low particulate UHV practice yet

Operational Concerns

When we have no direct eyes on cold vacuum:

- No gauge at cold, but
 - ▣ Thermal transpiration: Knudsen relation at equilibrium molecular flow region
$$N_{\text{cold}} = (T_{\text{warm}}/T_{\text{cold}})^{1/2} N_{\text{warm}}$$
$$P_{\text{cold}} = (T_{\text{cold}}/T_{\text{warm}})^{1/2} P_{\text{warm}}$$
- Signal of pressure wave delays significantly due to condensation
 - ▣ Up to 40 hours at leak rate of 10^{-6} torr.l/s at 2K, as at DESY, So Cold leak might not be noticed until RF or Cryo reactions
 - ▣ $d=4.3\text{cm}, L=75.3\text{m}$
$$t = 4.01 \times 10^{-2} Q^{-0.9595} \quad @1.9\text{K}$$





FIG. 6. Predicted time needed for the He pressure front to reach the instruments at the distant end with the cold bore tube at 1.9 and 4.2 K as a function of the leak rate in Torr l/s at 298 K.

E. Wallen, J. Vac. Sci. Tech A15(6)1997

R&D proposal: *realtime monitoring with RGA*

- slow leaks covered by huge cryo pumping of cavities, total pressure does not show problem
- Most experiment about cold leaks were done 15 years ago, and with total pressure gauge, $10^{-10} \sim 10^{-11}$ torr
- modern RGA is much more sensitive and inexpensive now, $10^{-14} \sim 10^{-15}$ torr partial pressures
- Changes of partial pressure ratio will indicate vacuum environment status evolving
- So, It may be possible to take preemptive measure before big failure occurs
- No isotherm data @1.8K for H₂, Air

R&D proposal: realtime monitoring with RGA



Summary

- Needs more input on vacuum requirement from SRF
- System shall be engineered to satisfy the requirement and cost effectively
- QC is critical for achieving a reliable vacuum system
- Preliminary calculation shown that necessary add differential pumping next to CM; 10^{-10} torr @CM entry is necessary
- work in near future
 - ▣ Calculate the pressure profile along beamline according to the lattice
 - ▣ Optimize the location and pumping scheme if necessary based on the pressure profile
 - ▣ R&D shall take place when engineering resource allocated

Ref: recommended machining fluids

Relton A-9

Tap Magic

Tapmatic #1 or #2

"Pearl" Kerosene by Chevron Chem CO

"Tool Saver" by Do All Corp.

Cutzol EDM 220-30

Sunnen Man-852 Honing Oil

Vytron Concentrate

Rust-Lick G-25-J

Wheelmate #203

Aqua Syn 55 by G-C Lubricants CO

Cold Stream Coolant by Johnson Wax CO

"Acculube" by Lubricating Systems Inc.

Micro Drop "Advanced System Lubricant" by Trico

Micro Drop "New Vegetable Based" by Trico

Rapid Tap

Trim Tap

RD2-195

Dip Kool 868

DIP Kool 862

Dip Kut 819H

No Sul #6871

Kool Mist #88

Cimcool 5 Star 40

Cimperial # 1011

Haloform CW-40


Trim Sol

Trim9106CS

CINDOL 3102

PenWalt #DP 1131

Ref: Vapor Pressures of H_2 , He



Ref: Outgassing Rates of some materials

Metals and Glasses	Desorption Rate (mBar-l/sec- cm ² x 10 ⁻¹⁰)	
	1 hr @ vacuum	4 hrs @ vacuum
Aluminum	80	7
Copper (mech. polished)	47	7
OFHC Copper (raw)	266	20
OFHC Copper (mech. polished)	27	3
Mild Steel, slightly rusty	58,520	199
Mild Steel, Cr plate (polished)	133	13
Mild Steel, Ni plate (polished)	40	4
Mild Steel, Al spray coating	798	133
Molybdenum	67	5
Stainless Steel (unpolished)	266	20
Stainless Steel (electropolished)	66	5
Molybdenum glass	93	5
Pyrex (Corning 7740) raw	99	8
Pyrex (Corning 7740) 1 mo. At Atm.	16	3

Ref. "Modern Vacuum Practice", Nigel Harris, pg 240

Ref: Hydrogen Isotherm

E. Wallen, J. Vac. Sci.
Tech A15(2)1997




FIG. 2. H₂ adsorption isotherms at 4.2 K on Pyrex, stainless steel, and Cu plated stainless steel (Ref. 20).

Ref: Helium Isotherm 1.9-4.2K

E. Wallen, J. Vac.
Sci. Tech A15(2)1997

